**Yottacontrol A-3290 WiFi Transmitter Quick Start**

The Yottacontrol A-3290 WiFi Transmitter had a two-way communication to communicate with the Modbus TCP/IP

Before the regular use, must finish the related setup process. And prepare below items to finish the setup.

1. Download and install the A-3290 connect cable **CAB-89** driver from below web link.
   http://www.yottacontrol.com/download/CAB89.rar

2. Prepare A-3290 and CAB-89 cable.

3. Open the A-3290 rear cover and use the CAB-89 to link the A-3290 and the PC. (Remove the battery)

You can set the WiFi parameters in the following figure.

LED Indication

Green & Red spark: When power on, the A-3288 need to press the password. When finish, press the START.

Green: Success to connect.

Red: disconnect.

SSID	12WIFI
Password	88888888
Tx Power	12
MAC Address	00-06-66-9d-67-45

Device ID	1

LED

On Time (ms)	30
Off Time (ms)	10

Sleep Mode	Disable
WIFI Key Password	

IP Address	192.168.1.1
Port	502
Modbus Start Address	16

Update   Factory Reset