



A-9N

*Network configuration directly
by NodeRed*

Modify A-9N network configuration by Nodered program: an easy way to configure A9N network

CONTENTS OF LISTpage 1/3

(I) SCAN the IP address

1.1 Use the 3rd party program or the green software Yottacontrol suggest(ipscan.exe).....page 2/3

1.2 Find A-9N IP addresspage 2/3

1.3 Key in the IP address in Browser(xxx.xxx.xxx.xxx:1880/ui).....page 3/3

(II) Update network parameters

1-1. Read current wire network and wireless network information.....page 3/3


1-2. Setup wire network configuration.....page 3/3




1-3. Setup wireless network configuration.....page 3/3

1-4. Setup the correct Time Zone of the device to active the correct RTC(Real Time Clock).....page 3/3

IP Range - Angry IP Scanner

Scan Go to Commands Favorites Tools Help

IP Range: 192.168.0.0 to 192.168.0.255 IP Range 

Hostname: YC22 IP  Netmask  

| IP | Ping | Hostname | Ports [0+] |
|---------------|-------|--------------|------------|
| 192.168.0.172 | [n/a] | [n/s] | [n/s] |
| 192.168.0.173 | [n/a] | [n/s] | [n/s] |
| 192.168.0.174 | [n/a] | [n/s] | [n/s] |
| 192.168.0.175 | [n/a] | [n/s] | [n/s] |
| 192.168.0.176 | [n/a] | [n/s] | [n/s] |
| 192.168.0.177 | [n/a] | [n/s] | [n/s] |
| 192.168.0.178 | [n/a] | [n/s] | [n/s] |
| 192.168.0.179 | 0 ms | YOTTACONTROL | [n/s] |
| 192.168.0.180 | [n/a] | [n/s] | [n/s] |
| 192.168.0.181 | [n/a] | [n/s] | [n/s] |
| 192.168.0.182 | [n/a] | [n/s] | [n/s] |
| 192.168.0.183 | [n/a] | [n/s] | [n/s] |
| 192.168.0.184 | [n/a] | [n/s] | [n/s] |
| 192.168.0.185 | [n/a] | [n/s] | [n/s] |
| 192.168.0.186 | [n/a] | [n/s] | [n/s] |
| 192.168.0.187 | [n/a] | [n/s] | [n/s] |
| 192.168.0.188 | [n/a] | [n/s] | [n/s] |
| 192.168.0.189 | [n/a] | [n/s] | [n/s] |
| 192.168.0.190 | [n/a] | [n/s] | [n/s] |
| 192.168.0.191 | [n/a] | [n/s] | [n/s] |
| 192.168.0.192 | [n/a] | [n/s] | [n/s] |
| 192.168.0.193 | [n/a] | [n/s] | [n/s] |
| 192.168.0.194 | [n/a] | [n/s] | [n/s] |
| 192.168.0.195 | [n/a] | [n/s] | [n/s] |
| 192.168.0.196 | [n/a] | [n/s] | [n/s] |
| 192.168.0.197 | [n/a] | [n/s] | [n/s] |
| 192.168.0.198 | [n/a] | [n/s] | [n/s] |
| 192.168.0.199 | [n/a] | [n/s] | [n/s] |
| 192.168.0.200 | [n/a] | [n/s] | [n/s] |
| 192.168.0.201 | 1 ms | A9N | [n/s] |
| 192.168.0.202 | [n/a] | [n/s] | [n/s] |
| 192.168.0.203 | [n/a] | [n/s] | [n/s] |
| 192.168.0.204 | [n/a] | [n/s] | [n/s] |
| 192.168.0.205 | [n/a] | [n/s] | [n/s] |
| 192.168.0.206 | [n/a] | [n/s] | [n/s] |
| 192.168.0.207 | [n/a] | [n/s] | [n/s] |
| 192.168.0.208 | [n/a] | [n/s] | [n/s] |

1. Execute ipscan.exe to scan all devices IP in the same domain.
ipscan software download address:
<http://www.yottacontrol.com/download/A9Ntools.rar>
2. Find the correct IP address of A9N.(192.168.0.201 in this case)

A-9N Configuration

System Info.

Network

IP : 192.168.0.201
Mac : e0:ff:f1:9e:a7:c2

Wireless Network

IP : 192.168.18.85
Mac : c4:6e:1f:10:fd:91

Ethernet

DHCP OFF/ON

IP Address (Ex. 192.168.0.2) *

Gateway (Ex. 192.168.0.1) *

DNS (Ex. 192.168.0.1) *

SUBMIT

WIFI Setting

SSID *
YOTTAM1

Password *
88888888

SUBMIT

Time zone

Time Zone Asia/Taipei

1. Key in the A9N IP address(192.168.0.201:1880/ui) in Browser address bar, then press Enter to visit Node-Red Dashboard.
(192.168.0.201:1880/ui) in this case

System Info.: Current wire network and wireless network information.

Ethernet: Initial is DHCP, switch to OFF to assign IP, then press SUBMIT to active.

WIFI Setting: Join to external WIFI, keyin the external WIFI SSID and Password, then press SUBMIT to active.

Time zone: select the correct Time Zone of the device to active the correct RTC(Real Time Clock).